


Assembly Instructions
MODEL NO.: N149
 MOBILE PEDESTAL


8/17

Quantity	Part No.	Part Name	Part No.	Part Name	Part No.	
A		Corner Metal Bracing Strap Handle 2 Pcs	B	Pin Clip 4 Pcs	C	25" x 1/2" Iron Adjuster Bar 2 Pcs
D		Castor Wheel 4 Pcs	E	Socket 4" x 1/2" 16 Pcs	F	Knob 1 Set

STEP 1



STEP 2



COMPLETED ASSEMBLY

IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.