



Knee Tilt

The pivot point for this mechanism is moved forward. This affords the user the ability to tilt back in the chair, while your feet remain on the floor. Additionally, there is no pressure asserted on the back of the leg thus eliminating fatigue.

Place handlebars in front of seat cushion as shown below.



- To lower the seat height, sit on the chair while pulling upwards on the lever beneath the right side of the seat. This handle is close to the back of the cushion.
- To raise the seat height, remove your body weight from the seat while pulling upward on the lever beneath the right side of the seat.
- To lock your chair in the upright position, push the handle bar on the left hand side of your chair inward towards the center of the chair.
- To unlock the upright lock, pull the handle bar on the left hand side of your chair outwards away from your body.
- To adjust the tilt tension of the chair to the user's body weight, turn the tilt tension knob counter-clockwise to decrease tension for lighter people and turn clockwise to increase tension for heavier people. (Small knob on the right side of the chair.)